

The RC SMART 2 remote control is designed for use with KEETEC devices. It offers manual as well as hands-free mode.


## AUTHORIZATION WITH RC SMART 2

RC SMART 2 remote control is able to operate in two modes:

1. **Hands-free mode:** In this mode driver authorization occurs automatically/ without the need to touch controls of the remote/ by the presence of RC SMART 2 in the vehicle. This mode is default.

2. **Manual mode:** In this mode it is required to push the button of the remote control in order to authorize the driver. This procedure is required before any ride while the ignition is turned on.

## DESCRIPTION OF RC SMART 2 REMOTE



**Activation/deactivation of hands-free mode** is possible at any time. In order to change the operating mode it is required to push the button 4 times quickly, while the 4th push will stay pressed for 2 seconds. LED indicator blinks accordingly: 1x at turn on, 2x at turn-off of hands-free mode.

## SETTING UP THE RANGE OF HANDS-FREE MODE

System offers to set one out of 4 levels of range settings. This determines distance from vehicle in which the remote control will be operable.

In order to change the range it is required to push the button 3 times quickly, while the 3rd push will stay pressed for 2 seconds. LED indicator blinks 1, 2, 3 or 4x according to level set. Levels are following one after the other.



- I. level - cca. 5m (blinks 1x)
- II. level - cca. 10m (blinks 2x)
- III. level - cca. 15m (blinks 3x)
- IV. level - cca. 20m (blinks 4x)

## LOW BATTERY INDICATION IN RC SMART 2

If the battery voltage drops below set threshold and at the same time the hands-free mode is active, the LED indicator blinks 2x every second. Replace the battery with the same type only (CR2450). After battery replacement, it is required to press the button on the remote to stop battery indication.

On some Keetec systems (Keetec Rider) the LED indication is complemented with acoustic indication - 3 beeps after ignition is turned on.

| Button                                       | Function                             | Conditions       | Indication                     |
|----------------------------------------------|--------------------------------------|------------------|--------------------------------|
| 1x button press                              | authorization                        | system is active | LED blinks fast                |
| 4x quick button press and hold for 2 seconds | ON/OFF hands-free mode               | anytime          | LED blinks 1x (ON) or 2x (OFF) |
| 3x quick button press and hold for 2 seconds | setting the range of hands-free mode | anytime          | LED blinks 1, 2, 3 or 4x       |