


MYCAR™ 2 Help

Important : In order to use the MYCAR™ 2 App, it will require a connection to the internet via cellular or WiFi.

Control display details



IDLE

There are no recent or pending commands.



ACTION IS PRESSED

A command has been pressed. If the icon remains blue, please verify your internet connection when using the application. If so and the problem persists, please deactivate and reactivate your internet connection to

re-establish the network connectivity.



ACTION COMPLETED

A command was sent to the remote car starter and the function was successfully completed. Processing delays may vary depending on vehicle model and installation method. **Troubleshooting :** If the

command was confirmed but was not executed, please try again. If the problem persists, please contact your retailer or **click here** (<https://www.mycar2.ca/support/>) for help.



ACTION TROUBLE*

The engine failed to remote start. A Trouble code will be displayed when details are available.

The engine has been remote started and the remaining runtime is displayed.

ENGINE STATUS*

 14:54



BATTERY LEVEL

These displays the vehicle battery voltage. This voltage display may vary based on the current vehicle status. If engine is running or battery is getting low will change the display indicator value. It is possible that a certain delay is required for the battery voltage to refresh.




AUX 1

etc...) and tap "done".


AUXILIARIES

There are 4 auxiliaries that could have been pre-configured by your installer. To modify a pre-configured auxiliary function: Access the Settings Section (**GEAR**). Tap an empty slot or an existing Auxiliary and associate one of the following item from the list (Trunk, Panic, Right Sliding Door, Left Sliding Door, Defrost,



SETTINGS

This will allow to edit the vehicle image, vehicle name, Auxiliaries and more.



TEMPERATURE DISPLAY

This will display the current temperature at your vehicle's location. This feature is using the current vehicle GPS position to get the current temperature at the vehicle's location. This will not represent temperature inside the vehicle nor the temperature when the vehicle is indoors.

** Depends on vehicle and installation method. In order to receive the vehicle statuses you must be located within the network coverage area and your smartphone must be connected to the internet via cellular or wifi.*

The MYCAR™ 2 device operates on 4G LTE cellular network which currently covers most of the North America and continues to quickly expand. Please consult our **coverage map** (<https://www.mycar2.ca/#coverage>) for more the most up-to-date information.

The MYCAR™ 2 device must be installed by a certified professional. Visit **our support page** (<https://www.mycar2.ca/support/>) for more details.

Multiple vehicles and users

You can allow up to 3 additional users to control your vehicle and you may have unlimited quantities of vehicles in a single application.

AUTHORIZING ADDITIONAL USERS

You can allow up to 3 additional users to control the vehicle from the application. To add new users simply follow the steps below.

1. The owner of the vehicle must generate an email to any additional users by using the Grant Access in the Authorized user list section
2. The additional user will receive an email asking him to download the My Cars app or launch the MYCAR™ 2 App if previously installed. The vehicle will be added automatically in the My Cars section
3. The Owner or any additional users can revoke the access to the vehicle at any time by revoking the access in the Authorized user list section


Volume Adjustment

Changing the volume of the app is based on your smartphone notifications volume level. Therefore changing the volume of your smartphone using the side buttons will change the audio level of the App.



GPS Functions

The basic GPS function included with your MYCAR™ 2 app is the "Instant Locate" function. To view or walk to the current vehicle position on your Apple Watch, follow the steps below.

1. From the MYCAR™ 2 control screen, tap the bottom arrow to slide the drawer menu up.

2. Tap this icon 

3. Upon entering the GPS map, the last known position will be displayed in the background as the app seeks the latest available position of your vehicle.

This icon  icon will display the vehicle position. This icon  icon will display your current position.

NOTE: The normal position refresh time is about every 2 minutes. Making a new inquiry within this 2 minute period will simply display the same position as the one previously displayed since the data has not been refreshed during that period. Once the 2 minutes are passed, making a new position inquiry will display the last known position in the background while the app seeks again for the latest available position of your vehicle.

*Automobility Distribution Inc. Reach us using our **Online Support***

(<https://www.mycar2.ca/support/>)** For any other information about this product, visit **our website (<http://www.mycar2.ca/>)